CROSLEY

CABINET PARTS

For Models: CS22AEXHW01, CS22AEXHN01
(White) (Almond)

REFRIGERATOR



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: CS22AEXHW01, CS22AEXHN01
(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
		LITERATURE PARTS
1	LIT2211602	Use & Care Guide
	LIT2204338	Service & Wiring Sheet
	LIT2211904	Energy Guide
	LIT628370	Modular Icemaker Service Sheet
2	2174748	Front Roller (2)
3	3400517	Screw
4	2196236	Roller (Rear) (2)
5	489427	Screw
6	2155013	Clip, Grille
7	489478	Screw
8	2156056	Shim
9	2196046	Hinge Top (2)
10	2196048	Shim, Hinge Top
11	489284	Screw
12		Hinge Cover
	1129262	White
	2150343	Almond
13	2171851	Hinge Bottom (2)
14	2196094	Filler, Wrapper
15		Grille
	2198469W	White
	2198469N	Almond
16	489497	Screw
17	489464	Screw
18	940139	Drain Fitting
19	1108438	Extension Tube
20	1108439	Clip, Drain Tube
21	2171938	Cover, Unit
22		Hinge Cover
	1119787	White
	1119789	Almond
23	549193	Clamp, Service Cord
24	489084	Screw
25	2155311	Door Closer, Lower Cam (2)
26	489483	Screw
27		Cabinet (Not a Serviceable Part)

REFRIGERATOR LINER PARTS

For Models: CS22AEXHW01, CS22AEXHN01

(White) (Almond)



Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2194744	Escutcheon, Meat Pan Control
3	2182757	Slide, Meat Pan Control
4	2182147	Louver
5	2171846	Release Valve
8	2196485	Stud Assembly (2)
9	3400894	Screw
11	489290	Screw (2)
13	2181796	Shelf Ladder
14	487539	Screw
15	2204329	Bracket, Water Filter
16	2204350	Cover, Water Filter
17	488163	Screw
18	2206039	Water Filter
19		Compression Nut
	2200083	(Outlet Tube)
	2204357	(Inlet Tube)
21	2152019	Air Diffuser Cover
22	1123919	Bracket Retainer
23		Water Tube
	2205987	Inlet
	2205988	Outlet
24	2208271	Air Diffuser Assembly
25	2204409	Air Diffuser Cover
26	2150331	Cover, Conduit
27	486298	Screw
29	2162085	Socket
31	2196171	Reservoir
33	527949	Light Bulb
34	2203266	Light Lens
35	2172840	Strap
37	488280	Screw (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Models: CS22AEXHW01, CS22AEXHN01

(White) (Almond)



Illus. No.	Part No.	DESCRIPTION
1	2163572	Shelf Assembly, Cantilever (3)
2	2173394	Cover, Crisper
3	2179259	Glass, Cover
4	2179350	Deflector
5	2189601	Cover, Meat Pan
6	2196481	Crisper Pan
7	2196162	Meat Pan
9	1125594	Retainer, Glass
10	2177986	Glass (3)
11	2196483	Shelf Assembly
12	2196485	Stud Assembly
13	2174150	Glass, Cover
14	3400894	Screw
17	8281158	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: CS22AEXHW01, CS22AEXHN01

(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: CS22AEXHW01, CS22AEXHN01

Illus. No.	Part No. (White)	Part No. (Almond)	DESCRIPTION
1			Liner (Not A Seviceable Part)
2	1115380		Slide, Ice Door
3	2171712		Door, Ice Compartment
4	8281158		Screw
5	489478		Screw
6	842534		Clip, Air Duct (2)
7	2196206		Support, Stud (4)
9	3400893		Screw
10	2176134		Grommet
11	2171707		Freezer Bin
14	2155572		Wiring Cover
15	489355		Screw
16	2209674		Bracket, Fill Tube
17			Slide, Basket
	1119293		Right Side
	1115383		Left Side
18	486298		Screw
19	1115373		Switch, Rocker Arm
20	2196483		Stud Assembly
22	3400893		Screw
25	527949		Light Bulb
26	2162085		Light Socket
27	2196207		Stud, Rear
28			Slide, Container
	1119237		Left Side
	1119293		Right Side
29	489100		Screw
31	2174265		Shelf (2)
	2174249		Shelf (1)

MOTOR AND ICE CONTAINER PARTS

For Models: CS22AEXHW01, CS22AEXHN01

(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS

For Models: CS22AEXHW01, CS22AEXHN01
(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1	2183728	Bracket, Motor
2	2188385	Motor, Dispenser
3	2152713	Solenoid Assembly
4	2149100	Gudie, Solenoid
6	1115374	Clip, Wiring
7	2206501	Wiring Assembly, Ice Dispenser
8	489399	Screw
9	2205716	Coupling, Motor
10	489478	Screw
11	2162085	Socket, Light
14	2196089	Ice Container
15	983668	Coupling, Conveyor
18	1119005	Spacer, Step (3)
19	1119007	Spacer, Flat (2)
20	1119006	Blade, Rotary
21	1119012	Blade, Rotary
22	1119013	Blade, Rotary
23	489235	Washer, Plain
24	1119009	Blade, Fixed (2)
25	2157405	Block, Blade
26	489229	Roll Pin
27	2181956	Conveyor
28	2196194	Drum
29	3400912	Washer
30	2171682	Floating Baffle
31	1119018	Nut, Bearing
32	2155231	Control Arm
33	1119020	Spring, Return
34	1119021	Retainer Clip, Rod
35	488886	Screw
37	2180348	Housing, Crusher
38	1119017	Deflector, Ice
39	489234	Washer, Plain
40	489236	Retainer Ring
41	2152021	Sleeve, Auger
44	2171709	Front Cover, Ice Container
45	527949	Light Bulb
46	2171706	Light Lens, Dispenser

REFRIGERATOR DOOR PARTS

For Models: CS22AEXHW01, CS22AEXHN01

(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: CS22AEXHW01, CS22AEXHN01
(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes Item 6)
	2194275W	White
	2194275N	Almond
2	2177105	Door, Compartment
3	489491	Screw
4	2187172	Shelf Bin (3)
5	2195327	Clip (4)
6		Door Gasket, Magnetic (Repair)
	2159073	Mist Beige
7		Handle, Center
	2186649W	White
	2186649N	Almond
8	2177962	Shelf Bin
9		Extension, Top
	2194971W	White
	2194971N	Almond
10		Extension, Bottom
	2194969W	White
	2194969N	Almond
11	2182178	Door Closer, Upper Cam
12	489420	Screw
13	2195950	Bracket, Door Stop
16	2182180	Thimble−Top
17	3400852	Screw
24	3400012	Screw

FREEZER DOOR PARTS

For Models: CS22AEXHW01, CS22AEXHN01

(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Models: CS22AEXHW01, CS22AEXHN01

(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes Item 8
	2211599W	White
	2211599N	Almond
		And Dispenser Front Parts)
2		Handle, Center
	2186649W	White
	2186649N	Almond
4	489491	Screw
5	2195327	Clip (4)
6	2195919	Door, Shelf (4)
7	3400012	Screw
8		Door Gasket, Magnetic (Repair)
	2159072	Mist Beige
9	2209680	Trim, Door Shelf
10	488500	Screw
11	2198271	Wire Harness
12	2182179	Door Closer, Upper Cam
13	489420	Screw
14	2195950	Bracket, Door Stop
15		Extension, Top
	2194971W	White
	2194971N	Almond
16		Extension, Bottom
	2194969W	White
	2194969N	Almond
17	2182181	Thimble−Top
21	3400852	Screw
23	2154473	Connector
24	2195916	Endcap (Right)
25	2195917	Endcap (Left)

DISPENSER FRONT PARTS

For Models: CS22AEXHW01, CS22AEXHN01

(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER FRONT PARTS

For Models: CS22AEXHW01, CS22AEXHN01

(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	489101	Screw
3	2194719	Retainer, Levers
4	2180209	Spring, Torsion
5	2196195	Pin
6	2180205	Door, Ice
7	2206423	Door Mechanism Assembly
8	2205686	Mechanism Delay
9		Grille, Overflow
	2183787W	White
	2183787N	Almond
10	2209718	Water Fitting Assembly (Includes Water Tube)
11		Lever, Ice
	2195089W	White
	2195089N	Almond
		Dispenser
12	2180224	Guide, Ice
13	2180200	Lamp Holder
14	2162361	Switch (4)
15	2183771	Bracket, Control
16	3406124	Bulb, Light
17		Lever, Water
	2195090W	White
	2195090N	Almond
		Dispenser
18	2180279	Switch Assembly (Also, order #19)
19		Overlay, Front Cover
	2211597W	White
	2211597N	Almond
20	2196198	Wire Assembly
21		Front Cover, Housing (Not Available, Order #23)
22	489000	Screw
23		Front Cover Assembly (Includes Items 18, 19, 20 & 21)
	2211598W	White
	2211598N	Almond
24	625834	Spacer, Switch (2)
25	2195051	Strain Relief
26	987121	Shield, Ice Door

UNIT PARTS

For Models: CS22AEXHW01, CS22AEXHN01

(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: CS22AEXHW01, CS22AEXHN01

(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1	486692	Speed Nut
2	2190685	Fan, Blade
3	2204242B	Condenser Assembly
4	489464	Screw
5	2208280	Clip, Wire
6	489099	Screw
7	934011	Clip, Tube (3)
8	2161302	Sleeve
9	2158826	Dampener
10	509812	Grommet
11	488687	Screw
12	4387731	Cover
13	4387767	Overload (Service Compressor Only)
16	2205764	Tube Suction
17	4387764	Capacitor (Service Compressor Only)
18	2204412	Start−Device, Combination (Start Relay and Overload) for Production Compressor Only
21	489478	Screw
22	2164518	Evaporator
23	2161324	Clamp
24	2176336	Fan, Motor
25	1105523	Tray, Evaporator
26	2149293	Heat Shield
27	2199167	Drier
28	2183453	Compressor (Includes Items 12, 13, 15, 17, 27 & 38) (Also Order 876765 Tube Kit)
30	2160500	Unit Mounting Frame
31	2211336	Unit, Harness
32	2181929	Fan, Motor Bracket
33	2188174	Heater, Defrost
34	2161330	Clip
35	2196155	Bi−Metal, Defrost
37	489387	Screw
39	2183042	Grommet (4)
40	489340	Screw
41	2196202	Air Baffle
42	2155547	Clip, Heat Shield
43	2182057	Unit Cover, Bottom
44	489396	Clip
48	2149717	Unit Mounting Rail
49	488624	Screw
50	1105612	Guard, Fan
52	2205813	Strap
53	489427	Screw
54	227991	Wire Connector
55	488649	Screw
63	2196152	Union

Following Parts Not Illustrated and Optional Parts Not Included

Part No.	
978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

REFRIGERANT CHARGE

5.5 oz.
(R−134A)

AIR FLOW PARTS

For Models: CS22AEXHW01, CS22AEXHN01
(White) (Almond)



Illus. No.	Part No.	DESCRIPTION
1	2182119	Fan Scroll
2	2155590	Retainer, Fan Motor
3	2161231	Air Scoop
5	2203591	Air Duct Freezer
6	2149544	Diffuser Air Duct
7	2149299	Fan Motor
8	2169142	Fan Blade
10	2176759	Fan Grommet (2)
11	2182146	Duct, Icemaker
12	2206504	Harness, Fan Evaporator, And Heater, Bi−Metal
13	2155788	Gasket Cover
14	2172840	Wire Tie
16	2203875	Gasket
17	2203840	Cover, Evaporator
18	489355	Screw
21	489478	Screw
22	2203595	Support, R.S
23	2203596	Support, L.S

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PARTS

For Models: CS22AEXHW01, CS22AEXHN01
(White) (Almond)



Illus. No.	Part No.	DESCRIPTION
1	2200137	Control Box
2	1110629	Mounting Bracket
3	3196537	Screw (4)
4	2149705	Light Switch
6	2188375	Defrost Timer (10 Hr.)
7	489398	Screw (2)
8	940014	Hole Plug
9	2198202	Thermostat Assembly
10	487869	Screw
11	2182195	Cam Assembly
12	1110560	Bearing Body
14	2196062	Clip, Damper Control
15	1110559	Pivot Arm
16	627068	Screw
17	2162085	Light Socket
18	2196001	Thermostat, Barrier
19	527949	Light Bulb
20	2206512	Control Box Harness
21	1115374	Clip, Wiring
22	1115375	Clip, Wiring
23	1123960	Connecting Rod
24	489285	Fastener, Push−On
25	2194977	Escutcheon, Control Box
26	2182111	Thermostat knob
27	2197871	Knob, Air Control
29	489203	Spring Washer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: CS22AEXHW01, CS22AEXHN01

(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: CS22AEXHW01, CS22AEXHN01

(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1	489084	Screw
2	2196157	Fitting, Water Tube
5	628379	Clip, Fuse
7	2181943	Tube, Water
9	489478	Screw
10	2206123	Valve, Solenoid
11	627018	Nut, Compression
14	489385	Tube Clamp
18	2174155	Cover
19	488649	Screw
20	628228	Mold & Heater Assembly (Also Order 542638
22	628356	Cup, Water Fill
23	2194711	Ejector
24	2182124	Ice Striper
25	2194712	Support
26	627796	Retainer, Thermostat
27	628397	Thermostat (Also Order 542369 Cement Alumilastic)
28	489322	Screw
30	489276	Screw
31	2171593	Shut Off Arm
32	628256	Harness, Wiring
33	628320	Bracket
35	628399	Module Assembly (Includes Items 37 and 38)
36	488208	Screw
37	628398	Motor
38	489136	Screw
40	1129179	Nut, Compression
100	4317943	Complete Icemaker Assembly

PARTS NOT ILLUSTRATED

For Models: CS22AEXHW01, CS22AEXHN01
(White) (Almond)

Illus. No.	Part No.	DESCRIPTION

Parts Not Illustrated and Optional Parts (Not Included)

Customer Touch−Up Material

	*350942	Primer, White (13 Oz. Spray Can)
	*350939	Enamel, Black (13 Oz. Spray Can)
	*350930	Enamel, White (13 Oz. Spray Can)
	*350956	Enamel, Almond (13 Oz. Spray Can)
	72017	Brush Touch−Up Kit (White)
	72107	Brush Touch−Up Kit (Almond)
	72032	Brush Touch−up Kit (Black)

* **CAUTION:** The spray paint is not to be used where the paint may make contact with the door gaskets.

Miscellaneous

	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Kit, Insulation (2 Pcs. x 3" x 24" X 48")
	876305	Kit, Insulation (14 Pcs. x 3" x 24" x 48")
	978941	Insulation, Fiberglass (63−1/2" x 35−1/2" X 2−5/8)
	876029	Kit, Foam Slab (30" x 32−1/2" x 1−1/2")
	505587	Sealer, Mastic (1 Qt.)
	503695	Cork, Sealer (1/4 Pound)
	511873	Touch−Up, White Porcelain (2 Oz.)
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1−1/4 Oz.)
	606755	Bag, Insulation (36−5/8" x 46")
	799833	Kit, Evaporator Repair (Aluminum Epoxy)
	833938	Kit, Terminal Connector
	2182097	Ice Container Assembly
	2152735	Ice Crusher Assembly

Refinishing Material

	799340	Enamel, Black (1 Qt. Uncut)
	799344	Enamel, White (1 Qt. Uncut)
	978883	Enamel, Almond (1 Qt. Uncut)

TORX SCREW WRENCH

	1117510	Torx Key